build 1.0.0.1

FaxCore Konica Minolta Connector User Guide

August 30, 2012

Table of Contents

Sending a Fax from MFP (iOptions Web Browser) 3

Printing Faxes from FaxCore Inbox 7

Sending a Fax from MFP (Native Open API) 9

Technical Support 10

Sending a Fax from MFP (iOptions Web Browser)

Select APP button to list the applications that is registered on MFP

Select "**FaxCore**" from the application menu.



Login with your FaxCore username and password.



Enter recipient information and a subject/note that will appear on the fax cover page then select "**Continue**".

Note: *You can also select a recipient from your FaxCore address book by selecting the "**Recipient**" button, select a **"Cover Page"** or setup addition options with the **"Fax Options"** button.*



This will now take you to the Scan Settings panel. You can leave the scan settings as default or change the settings to your preference.

Finally, place the document on the document feeder and hit the start button.

The application will now submit the scanned document to FaxCore to be faxed out. When the process completes, you will receive a confirmation and can now exit the application.

Printing Faxes from FaxCore Inbox

Select "**FaxCore Inbox**" from the application screen.



Login with your FaxCore username and password.



Select **"Preview"** on the fax that you want to print.



Enter the number of copies you want to print and select **"Print"** button**.**



Sending a Fax from MFP (Native Open API)

Select APP button to list the applications that is registered on MFP, then select FaxCore Basic (if you only have a single APP registered on the MFP, the MFP will skip this step).



Enter a Fax Number (optionally, a recipient name – not required at all) and hit the “Start” button on the MFP.



Technical Support

If you face any problem or have any questions, please contact your FaxCore representative. You can also send email to **support@faxcore.com** or login to our support site at **http://crm.faxcore.com/portal**